E-MAIL FILES FROM TWM

1. Start TWM and go to recall mode then click on the open button.

🔁 TWM - *:*	
File Mode Option Tools Help	
C Acquire Mode	
<u>R</u> ecall Mode Group:	Cobra
Well:	* NO WELL SELECTED *
F2 Created On:	
Data Files	Allows the user to recall a Data Set previously acquired in the field for a given Well. In addition to test data (e.g., Dynamomter, Acoustic) the Data Set also contains a snap shot of well data from the Well File at the time of the acquisition.
<u>Save</u>	Saves any changes the user may have made to well data or any updates to the analysis.
Close	Close current Well File.

2. Place your mouse over the well that you want and click the right mouse button. This will bring up a utility box, Choose e-mail files from this box and a file transfer box will open up.



From this box, select the file or files you want to e-mail and click OK button.

File Transfer Selection	
🔽 Include Base Well File	
Data Files	ОК
	Cancel
10/22/2008 14:23:46	
Place a check in the box or boxes to choo want to select.	se which files you

3. After clicking ok, if you have Microsoft outlook set up on your computer. Outlook will open up with the files you selected attached to a new message. You will then type the persons e-mail address into the to box and hit the send button.

123	145	
This mes	sage has no	t been sent.
	To	ken@echometer.com
-	Cc	
Send	Subject:	
$\overline{\mathbf{A}}$	Jubject.	
-	Attached:	□ RvogtXa8.020 (280 KB); I RvogtXa8.bwf (6 KB)
	Attached:	I RvogtXa8.020 (280 KB); I RvogtXa8.bwf (6 KB)